


**Reservdelar**

**Spare Parts**

**DC 3800 Twin Turbo**



**Svenska**

Art nr	Benämning
2401	Sugslang std Ø=50
3077	Skarv 50
40453	Filterrensklaff
40488	Chassi (cyklon)
40489	Chassi (hjul)
40497	Hjul
40539	Plasthandtag
40577	Axel
4089	Spännbandshållare
41505	Mjukstart 120V

Art nr	Benämning
41506	Mjukstart 230V
42012	Kona med utmatningsklaff
42024	Mikrofilter
42025	Finfilter, polyester
42026	Finfilter, cellulosa
42030	Fjäder
42031	Cyklon
42081	Ljudabsorgeratsats
42201	Centralrör
42299	Plastsäckshållare

Art nr	Benämning
42366	Spännlås
42404	Lock
4313	Spännband
432100	Startapparat
4322	Turbopump 2,0 kW 220/380 V 50 Hz
4866	Gummimanschett
4873	Länkhjul
805201	Skjutspjäll
94122-C	Bruksanvisning i original DC 3800c Twin Turbo

**English**

Part No	Description
2401	Hose std Ø=50 per mtr
3077	Joint 50
40453	Filter cleaning flap
40488	Chassis
40489	Chassis (wheel)
40497	Wheel
40539	Handle
40577	Axle
4089	Strap holder
41505	Soft-start 120V
41506	Soft-start 230V

Part No	Description
419006	Turbopump, 4 HP, 230/460 V 60 Hz, UL, CSA
42012	Cone with unloading flap
42024	HEPA filter
42025	Fine filter, polyester
42026	Fine filter, cellulose
42030	Spring
42031	Cyclone
42081	Sound absorbing set
42201	Central pipe
42299	Plastic sack holder

Part No	Description
42366	Fastener
42404	Lid
4313	Strap
432100	Motor overload
4322	Turbopump 2,0 kW 220/380 V 50 Hz
4866	Rubber connector
4873	Wheel
805201	Shutter
94122-C	Original instructions DC 3800c Twin Turbo